



CH-CM0206 Double Servo Auto-Cut CNC Carbide Rod Cut-Off Machine - Single Rod

Operation Manual

Machine Serial No. 202107-92

Rush Machinery, Inc.
4761 Route 364
Rushville, NY 14544 USA

Tel: 800-929-3070 (Toll Free - USA & Canada)
or +1 585-554-3070
Fax: 585-554-4077

Email: mail@rushmachinery.com
Website: www.rushmachinery.com

Table of Contents

1. Basic Machine Information.....	3
1.1 Product Description	3
1.2 Material Characteristics	3
1.3 Product Features	3
1.4 Machine Specifications.....	3
1.5 Definition of Axis	4
2. Safety Regulations	5
2.1 Noise Generation	5
2.2 Dangerous Points	5
2.3 Work Area	5
2.4 Qualified Operator	6
2.5 Personal Protective Devices	6
2.6 Safety Measures at the Installation Site.....	6
2.7 Safety Devices	6
2.8 Safety Labels	8
2.9 Position of Safety Labels	9
2.10 Emergency Handling and Operation	10
2.11 Door Interlock Device	11
2.12 Grinding Wheel Protective Device.....	12
2.13 Treatment of Waste	12
2.14 Environmental Illumination Requirements	12
2.15 Andon Colors Indicated Light Meaning.....	13
2.16 Release Procedure.....	13
3. Moving and Installation	13
3.1 Moving the Wooden Case	13
3.2 Dismantling	14
3.3 Installation and Connections	14
4. Basic Operation.....	16
4.1 Machine Check Before Operation	16
4.2 Machine Start and Stop.....	16
4.3 Material Load and Unload	17
4.4 Control Panel Diagram and Descriptions	18
4.5 Solenoid Valve	19
4.6 Lubrication Equipment (Slide-Way Lubrication).....	19
4.6.1 Operating Instructions	20
4.7 Wheel Replacement and Detection.....	20
4.8 Contact Position Setup.....	22
4.9 Length Compensation.....	23
4.10 Set-up for large diameter rods over 1 1/4" (32mm)	24
4.11 Program and Page Update	28
5. Menu	30
5.1 Input Parameter.....	30
5.2 Front Page.....	31
5.3 Start Page.....	31

5.4 Auto Mode Page 1	32
5.5 Auto Mode Page 2	33
5.6 Auto Mode Page 3	34
5.7 Manual Mode Page 1	34
5.8 Manual Mode Page 2	35
5.9 Manual Mode Page 3	35
5.10 Parameter Setting Page 1	36
5.11 Parameter Setting Page 2	37
5.12 Parameter Setting Page 3	38
5.13 Parameter Setting Page 4	39
5.14 Position Setting Page 1	40
5.15 Position Setting Page 2	40
5.16 Position Setting Page 3	40
5.17 System Parameter Page 1	41
5.18 System Parameter Page 2	41
5.19 System Parameter Page 3	41
5.20 System Parameter Page 4	42
5.21 Alarm Message	42
5.22 Alarm Troubleshooting.....	42
6. Maintenance	44
6.1 Coolant Oil Specifications: Material Safety	44
6.2 Grinding Wheel Diagram and Photograph	45
6.3 Tool Box List.....	45
6.4 Other Machine Parts	45
6.5 I/O Table.....	46
6. Rush Machinery Warranty	50
Appendix A: Recommended Spare Parts List	51
Appendix B: Optional Accessories	52
100L Filtration System	52
Fire Suppression System	52
Mist Collector	52

1. Basic Machine Information

1.1 Product Description

The CH-CM0206 Double Servo Automatic Cut-Off Machine is used to execute cut-off function. It is used for cutting tungsten carbide bar, hardened steel and Carbon tube. **Other uses are strictly prohibited. It is not applicable to process flammable materials such as magnesium and rubber, wood, and poisonous materials, etc.**

A full cover with a metal plate is provided to protect the operator's safety. Conversational program settings and a touch screen allows the operator to easily set up parameters to achieve the ideal working condition.

1.2 Material Characteristics

Steel derives its mechanical properties from a combination of chemical composition, heat treatment, and manufacturing processes. While the major constituent of steel is iron, the addition of very small quantities of other elements can have a marked effect upon the properties of the steel. The strength of steel can be increased by the addition of alloys such as manganese, niobium, and vanadium. However, these alloy additions can also adversely affect other properties, such as ductility, toughness, and weldability.

1.3 Product Features

- ❖ Automatic loading and unloading; no collision of workpiece end face; no need for manual loading or unloading.
- ❖ Executes precise cut-off.
- ❖ User-friendly interface: numerical values for processing can be changed quickly.
- ❖ Wheel wear of the outer diameter can be compensated to ensure grinding size consistency.
- ❖ X-Y table controlled by servo motor.
- ❖ High precision grinding spindle.
- ❖ Material operation in V tray provides an excellent after-cut surface of bars.

1.4 Machine Specifications

Machine Dimensions: 2000mm L x 1300mm W x 1880mm H; 800 kg weight

Machine Capacity:

Item	Dimension (mm) min - max	Dimension (inches) min – max
Bar OD	1.4 – 40	0.055 - 1.57
Bar Length	80 – 420	3.15 – 16.54
Min Cut Length	5	0.197

Pneumatic Requirements:

Rated Pressure	6.0 bar
Humidity	Compressed air must be dried.
Compressed Air Cleanliness	Compressed air must be filtered.
Compressed Air Consumption	50 L/min.

Electrical Requirements:

Input Voltage	3Ø 220V AC
Frequency	60 Hz
Power Consumption	4.5KW
Current	20A
Breaker Capacity	20A
Wire Size	12 AWG


Environmental Requirements:

- ❖ Machine should not be under direct sunlight.
- ❖ The ambient humidity must be less than 95% and free of condensation. Excessive humidity must be avoided due to many sensitive electronic parts.
- ❖ The ground of the shop floor must be flat for machine installation. Unstable installation may lead to poor quality of control and other side effects from coolant and lubrication system.
- ❖ The machine must not be subject to chips scattered from other machines or airborne dust.
- ❖ Required maintenance space must be reserved. The door should be able to open freely. The chip bucket and coolant tank can also be pulled out from the machine without interference.
- ❖ The ground must be capable of absorbing the vibrations of other machines.
- ❖ If vibration problems cannot be solved and still transfer to machine, then it should be quantified by using a vibrometer. The vibration level must be lower than 0.5G.

1.5 Definition of Axis

X-Axis: Feeder

Y-Axis: Cutting Wheel



2. Safety Regulations

The CH-CM0206 is equipped with safety devices to protect the operator from harm. The operator must have proper accreditation and training and must read the operating instructions carefully before using the machine. The following risks may occur due to operator error:

- ❖ Injury to the operator.
- ❖ Damage to company machinery or other tangible assets.
- ❖ Reduced machine efficiency.

Any machine modification made without permission is prohibited, as modification would affect the equipment and personnel safety. The operations, services, and maintenance situations described in this manual must be strictly obeyed.

Added devices should not impact the safety regulations/operation manual.

Emergency safety switches must be able to operate by touch.

2.1 Noise Generation

Continuous noise generation by the CH-CM0206 Cut-Off Machine is below 70 dB (A), not including those from the optional oil mist collector.

The figures quoted are emission levels and are not necessarily safe work levels. While there is a correlation between emission levels and exposure levels, this cannot be used reliably to determine whether further precautions are required. Factors that influence the actual level of workpiece exposure include the duration of noise (i.e., the number of other adjacent machines). **The permissible exposure levels can vary from country to country.**

2.2 Dangerous Points

CH-CM0206 uses a high-precision grinding spindle. Maximum speed is as high as 2300 RPM. Contact with the rotating spindle may cause injury to the operator from friction or tearing.

Debris particles may spring off rotating defective objects and hurt eyes that are not protected.

Stop equipment operation before maintenance and cleaning.

2.3 Work Area

The work area is in front of the machine where you can see the user interface.

- ❖ Machine main power switch



Emergency Stop Button



Main Power Switch


Internal Inspection Schedule:

- ❖ At each restart (after operation is interrupted)
- ❖ Once every week while machine is in operation
- ❖ After each maintenance or repair



Safety Door Switch

2.8 Safety Labels

Safety Sign	Description	Mark
	Position of fork lifter fork	A
	Caution label asking operator to use eye protection	B
	Danger! Hazardous voltage	
	Warning! Electric Shock	D
	Marking of inlet/drain port for oil	E
	Main Power Switch	F
	Safety sign to ask operator to avoid putting hand in	G
	Motor rotation direction	H
	Warning about operating machine without guard in place	I

2.9 Position of Safety Labels



2.10 Emergency Handling and Operation

When the emergency and safety function is started, the machine (including the motor) will be stopped and all commands reset.

In case of an emergency stop with the emergency switch, the main magnet contactor inside the main power distribution box is shut off. Unless the power on the factory side is turned off, the main breaker and the primary side of the main magnet contactor has been still energized. So, be sure to turn off the main breaker on the system and factory side. **Touching terminals may cause fatal electrical shock.**




The emergency stop switch has the following features:


- ❖ The emergency stop circuit is independent.
- ❖ Pressing the emergency stop switch shut off all power to the system.
- ❖ When resetting the emergency stop condition, turn the switch right. Resetting the switch enables the user to turn on the power of the system.

Operation procedure:

1. Press the emergency stop switch when danger is recognized.



2. After pressing the emergency stop switch, keep it in the off position. To turn on the power, turn right and reset the emergency stop switch again. The emergency stop switch becomes on and enables the operator to turn on the power.



2.11 Door Interlock Device

Door open procedure:

1. Turn the mode key selector to setting mode.
2. Open the interlock door.
3. When the guard is opened, the machine will stop moving.



Keep the door open:

- ❖ When the machine power is on
- ❖ When using the key to turn to the open position (Interlock function off)
- ❖ If you need to cancel the safety function from system parameters




Keep the door closed:

- ❖ When the machine is running, the door is locked and cannot open
- ❖ When the power is off, the door is locked

Reset the safety door lock:

- ❖ When the system safety door lock function is on, turn the switch below unlock position



2.12 Grinding Wheel Protective Device

Each machine will attach a wheel cover to protect the operator. The cover should not be taken off without the permission of the machine supplier.



2.13 Treatment of Waste

The disposal of wastes (such as oil coolant and chips) must comply with local regulations.

Item	Treatment
Cooling Oil and Coolant	Ask the supplier to recycle
Waste of material powder (Carbide and HSS)	Ask qualified powder recycling company to handle the waste

2.14 Environmental Illumination Requirements

Keep area around machine well-lit (>300 lux) and dry. This will protect the operator and provide a sufficient working condition.

2.15 Andon Colors Indicated Light Meaning

Color	Meaning	Explanation
Green	Normal	The green light will be lit when the machine is in normal operation. Program edits may not be made at this point.
Yellow	Program End	After operation, the yellow light will be lit, and program edits can be made.
Red	Emergency	The red light will flash twice per second when the machine is signaling an alert. The red light will also be lit when the emergency button is pressed.

2.16 Release Procedure

If the personnel is trapped by axes movement, then follow this release procedure:

Power ON:

1. Press the EMG STOP button to stop all movements.
2. The power of spindle and axis movement will be removed.
3. The interlocking doors (front door, magazine door) can then be opened.

Power OFF:

1. Make sure the EMG STOP is pressed.
2. Turn on the main breaker switch.
3. The interlocking doors (front door, magazine door) can then be opened.

3. Moving and Installation


3.1 Moving the Wooden Case

The CH-CM0206 Cut-Off Machine arrives fixed in a wooden case; total gross weight is 1020 kg.

To move the wooden case, please use a forklift and follow these instructions:

- ❖ Keep machine upward during delivery and transportation.
- ❖ Do not shake the machine or let it fall. Watch for the position of the center of gravity.
- ❖ Only move the machine with a forklift.
- ❖ Minimum lifting weight for the forklift is 2000 kg.
- ❖ Watch your surroundings while moving the machine.

The center of gravity is around the central position.



The forklift truck should have a minimum capacity of 2 tons.
The lifting forks' extension length minimum is 2.5 m.


3.2 Dismantling

Once the machine is ready to be removed from the crate, please dismantle the wooden case then move the machine by forklift to the exact position for operation. Then take off all wrap and protective film.


3.3 Installation and Connections

The CH-CM0206 Cut-Off Machine must be installed on stable and fixed ground.


1. Use 4 base screws for level adjustment.



2. Install power connections (qualified electrical technicians only): 220V 3-phase 60 Hz



Power Connection



Earth Ground Terminal

3. Install pneumatic source connection lines at the connection points behind the machine.
 - a. Pressure: 6 bar
 - b. Pneumatic Inlet: 90° copper fitting, 3/8" female thread type; 3/8" male thread type plus C type quick fittings 3/8" male PT thread



4. Install the inlet hose of coolant and outlet pipe of return coolant, as well as the coolant motor power.



Coolant Inlet




Coolant Outlet

5. Connect the pipe of oil mist exhaust and power. The outlet of the hole is 100mm out diameter.
6. Place coolant outlet hose with attached filter in the drain grate.



7. Connect the filter pump plug to power receptacle on the machine.



Power Plug Receptacle



Filter Pump Line/plug

8. Fill coolant tank with 27 gallons of water and rust inhibitor. Refer to 100L filtration manual for full details.

4. Basic Operation

4.1 Machine Check Before Operation

Before daily operation, check the following:

- ❖ Appearance of the machine to see if there are any abnormal conditions.
- ❖ Inside of the machine, especially the X axis (feeder) and Y axis (Cut-off wheel) position
- ❖ Appearance of the cut-off wheel (rotate the wheel by hand with gloves) to see if there is any chip on it. If the wheel is not in good condition, the wheel needs to be changed.

4.2 Machine Start and Stop

Machine Start:


1. Connect the 3-phase wire power.
2. Turn on the power switch.
3. Turn on the panel power switch.
4. After program start, release the emergency button.
5. Press the cutting button to return all axes to home position.

Machine Stop:

1. Switch to manual mode.
2. Press the emergency button.
3. Turn off the panel power switch.
4. Turn off the main power switch.
5. Disconnect the 3-phase wire power.

4.3 Material Load and Unload


Material Load:



1. Measure the material total length and diameter.



2. Put material into the load box, making sure the material is against the right side.



3. Adjust the loading box fork to make sure the fork's depth is good for the material OD.



4. In manual mode, check the load function of the machine.

5. Check to make sure the fork can lift the material.




6. Check to make sure that load box can filter bar to let only one bar go up to waiting position through the load box screws (or spring ball).



7. Check that the bar will stop at standby position by the proximity switch.

Material Unload:



1. Material will be pushed out into the unload box with offcuts. Collect the finished material from the unload box.

4.4 Control Panel Diagram and Descriptions




Main Power: On/off switch for machine.

Mode Switch: Switch to Manual/Single/Auto mode. Control by key; single mode can control the machine light as well.

Motor: On/Off for the cut-off motor. When the machine cover is open, the motor will not function, even if the motor is switched to on.

F-R / U-D: Switch to control the Y axis (move Feeder forward/backward) and X axis (move saw up/down) in Manual mode



Moves the cutting wheel up/down (Jog mode) when controlling X axis in Manual mode

Moves the feeder forward/backward (Jog mode) when controlling Y axis in Manual mode


Emergency Stop: Press when you need to stop the machine immediately.

Cut Speed: Control the cut-off speed when the machine is working.

Charge In / Single: Load the material manually. Single mode can turn on the light.

Cutting: Switch to Auto mode and press this button to start auto cutting immediately. When the machine is open for the first time to start work, press this to return all axes to home position.

4.5 Solenoid Valve



Solenoid Valve 8 Sets (Left to Right)							
1	2	3	4	5	6	7	8
Left Finger	Right Finger	Load Cycle	Wheel Detect	Wheel Spindle / Clamping	Short Material Load	Load Cushion Cylinder	Off Cut Blow Out

4.6 Lubrication Equipment (Slide-Way Lubrication)

Centralized Lubrication Device

When equipment is activated (power is ON), the centralized lubrication device will start to function. The buzzer will sound and send warning signals.



Oil tank capacity: 2 L

Oil supply pressure: 7 bar (max.)

Lubrication time: 10 sec. each time per 180 min.

4.6.1 Operating Instructions

Oil Supply Pressure: The rotating screw in front of the lubricating device can be used to adjust the oil pressure (works together with the Instant Supply Oil button). Oil supply pressure will be shown only when lubricating. During intermittence, the pressure gauge shows 0.

Instant Supply Oil: Press this button (“F”) to immediately supply lubricating oil.

Oil Return Tank: Oil in the return tank must be discharged daily to avoid spills from excessive oil and contaminating the ground. You can observe the oil return situation to understand whether the lubricating device and return oil pipelines are functioning normally. When there is no oil coming out from the back, please notify the manufacturer to find out the cause.


4.7 Wheel Replacement and Detection

The wheel must be replaced if the diamond wears out or there is a rupture on the out diameter.

1. Move the wheel cover upward.




2. Use a wrench to loosen the screw nuts (26 and 14 mm) clockwise. It is a left-handed thread.



3. Measure the diameter of the new wheel and lock on the machine.
4. Advance to Saw Probe set page.

5. Input the actual cutoff wheel diameter to “New Cut OD parameter”



6. Turn on the motor.

7. Press the “New Cut Probe” and “Cutting” button to re-detect the wheel edge.




- Please follow Step 7 three times.

4.8 Contact Position Setup

X Axis Setup:


- Take a bar and measure the length, then put into Cutting V tray.



- Switch to control Y axis (up/down). Move cutoff wheel downward to the V tray cutoff position by hand wheel.
- Switch to control X axis (feeder). Move the feeder with bar until it touches the surface of the cutoff wheel. Pressing “Left Press Down” and then “Left Press Release” clamp fingers will raise to view wheel position relative to material.




- Press “Feed HM to Cut HM” button to input the center position record to system. Finish the position setup.




Y Axis Setup:

1. Measure bar OD and Saw OD and input dimensions. Put bar into V tray cutting position.
⚠ Test bar must have a diameter smaller than 7mm for this procedure.




2. Input the bar length.
3. Turn motor on.
4. Switch to control the Y axis, using the hand wheel to move saw downward (X1 move speed suggested).
5. Make the wheel OD contact the bar OD, then stop.



6. Press “Cut (Y) Center to V bottom” to input the position.

4.9 Length Compensation

- ❖ If each piece is incorrect, please check wheel width parameter first. If actual value is 1mm, please set as 1.05–1.08 to take the wheel run out into consideration.



- ❖ If only the last piece is incorrect, please adjust the feeder position. If less than actual value, decrease. If more than actual value, increase.



4.10 Set-up for large diameter rods over 1 ¼” (32mm)

Note: Any time you’re cutting a rod over 32mm (1.25”) in diameter you need to remove the fingers from the clamping arms and remove the splash guard.



Finger




Clamping Arm



Splash Guard


- 1) Navigate to Systems Set screen sys-2. Change “Max feedback error limit (Y)” from 2.500 to 9.000 and Y rotate Radius (Rb) from 212.000 to 182.000



2) Perform Contact POS Y Axis Setup.

Y Axis Setup:

- Navigate to Parameter Set page 1.
- Enter the Cut wheel OD, Rod OD and Rod length and enter in appropriate boxes.
Rod OD needs to be 7mm (0.250") or less.



C) Navigate to Manual Mode page 1




D) On the control panel, switch to Y axis control and Manual mode.




E) Use the hand wheel to move the saw downward until the saw just touches the bar OD (X1 speed suggested).

F) Navigate back to Parameter Set page 3 and press the RED “Cut Y center to V bottom” button.



- 3) Remove the fingers from the clamping arms.
- 4) Place 38.08mm (1.5”) test bar in the V tray just to the left of the cutting slot so the saw will not actually cut the rod.
- 5) Navigate to Parameter Set page 1.
- 6) Enter the Cut wheel OD, Rod OD and Rod length and enter in appropriate boxes.
- 7) Navigate to the Auto Mode page1 and note the values for the 1st, 2nd, and 3rd Cut POS.
- 8) Navigate to the Manual Mode page1 and using the hand wheel lower the saw blade until the Y axis has reached the 3rd Cut POS position noted previously. Check to make sure that the saw blade depth has just reached the bottom of the test rod.
- 9) Without moving the saw, navigate back to the Auto Mode page1 and checked that the 1st, 2nd, and 3rd Cut POS have all completed and have turned RED.



- 10) If all Cut POS's are RED, then all the cuts have been completed.
- 11) If the saw blade is not to the bottom of the test rod, then make the Radius Rb in the System parameters (previously set to 182.000) a little larger and try the Manual test cut again. If the saw blade has gone below the test rod before the 3rd Cut POS has turned RED and completed, then make the Radius Rb a little smaller. It is recommended to change the radius by 0.5-1.0 degree at a time. If you get a "34 Over Cut POS feedback limit" error, then increase the "Max feedback error limit (Y)" by 0.5 at a time and try the test cut again.

4.11 Program and Page Update


1. Save program on the USB and plug into the port on the screen backside.




2. Open machine and choose "Download"



3. Choose "No" on the box that says, "Do you want to remove it all?"



4. Choose “No” on the box that says, “Do you want to delete it all?”




5. Choose the dlz file you need to download and press “Download”



6. Go into system Set.



7. Input password: 89823631



8. Page 4: choose “Controller Program update”



-
- The screenshot shows the Syskey 4.0 software interface. The title bar at the top reads "Syskey 4.0". The main window is divided into three vertical panels. The left panel, labeled "Function", contains buttons for "Power Off Control Off", "Left press Down", "Cut auto probe", "Load cushion", and "Cylinder disable". The middle panel, labeled "Password", contains a numeric keypad (0-9), an "OK" button, and an "ESC" button. The right panel, labeled "Function", contains buttons for "Bar height Detection Off", "v pitch", "Control close", and "move bar 1". At the bottom, there are four tabs: "Main", "Controller Program update", "Sys-1", and "Sys-2". The "Main" tab is currently selected.

-
- UTPC Controller System Update
- | | | | |
|--------------------|-------------------------|------------|------|
| UTPC Control Type | UTPC009V2.Q2.2012/10/23 | 2015/05/11 | EXIT |
| PLC Program Update | JSD4302 | 09:36:30 | EXIT |
- The software controller program,
Please Edit ***.CNC, stored in PCN
And then inserted into the CPU jack of the machine bedrail
- Upload to PLC program
Press any Key
- OK EXIT

-
- << UTC Controller System Update >>
 File Open
 Previous Cancel Extensions: CNC
 CNC#-140116.CNC
 CNC#-140116r1.CNC
 CNC#-140225OK - 複製.CNC
 JLG0206-150130.CNC
 CHC001M2-141028.CNC
 SRCO-150213.CNC
 JLG0206-150336.CNC
 JLG0206-150410.CNC
 File: JLG0206-150410.CNC
 Page UP
 Page DOWN
 OK

- Rush Machinery**
Grind better.

The image shows a wireframe diagram of a machine, likely a grinding machine, with a central grinding wheel and a workpiece being processed. The machine has a sturdy base and a vertical support structure.

- | | | | | |
|----|---------|-----|------|------|
| 中文 | English | 三本頭 | SIZE | 3218 |
|----|---------|-----|------|------|

5.2 Front Page




Switch between
English and Chinese

Display program no.

5.3 Start Page

Whenever you open the machine, press the green “Cycle Start” button to return all axes to home position. Please be aware that whenever they go back to home position, it should be executed in Manual mode.



Auto Mode: Enter auto mode.

Manual Mode: Enter manual mode.

Parameter Set: Go into parameter setting page and set up the basic processing parameter.

System Set: Enter system parameter setting page and set up system parameters.

Position Set: Enter position setting page and set up the working position.

Alarm Page: Enter alarm message and check the alarm record.

5.4 Auto Mode Page 1

Mode of the machine Direction of axis Cutting Speed All axes' present position

(Manual)	(U-D)	F	2000.000	X	0.000	Y	0.000
CutD1	7.857	CutW1	0.042	0.287	0.018	Safe Load Height	
BD	0.167	BL	3.996	0	1	0	Saw cushion POS
Lx	0.150					Saw contact POS	
L1	1.500	N1	2	0	1st CUT POS		
L2	0.000	N2	0	0	2st CUT POS		
L3	0.000	N3	0	0	3st CUT POS		
XX	0.721	Program Abort !				Over cut Endpoint	
-->	18.882					Cycle Time	
Main	unit inch	7	5	Auto-1	Auto-2	Auto-3	

Number of Pieces Number of Bars

BD	Bar OD			
BL	Bar length			
LX	Facing length			
L1	First cut length	N1	L1 quantity	Includes Current Cut
L2	Second cutoff length	N2	L2 quantity	Includes Current Cut
L3	Third cutoff length	N3	L3 quantity	Includes Current Cut
xx	Offcut			


Safe load height		Safety height of Saw when feeder pushes in material		
Cut cushion POS		Cushion distance of cutting wheel before touching bar		
Cut contact position		Position when the wheel touches the bar		
1 st cut position	See picture below	Cycle Time	One Cut Cycle Time	Whole Bar Cycle Time
2 nd cut position				
3 rd cut position				
Wheel position display will be red when achieved			Distance between feeder to saw, left side	Detect Count: work how many cuts you need, then the machine will check wheel diameter automatically

5.5 Auto Mode Page 2

X	0.000	Y	0.000	ProgFile :	CH-CM0206-170824
Cut OD D1	7.857	inch	Bar OD (D)	0.167	inch
Cut width W1	0.042	inch	Bar length (L)	3.996	inch
Cut remnant	0.287	inch	Finish Tool	7	(pcs)
P to S distance	18.882	inch	Finish Bar	5	(pcs)
Cut probe POS	1.371	inch	Working speed	2000.000	inch/M
L Press release from N	0	cnt	Cut RPM	2000	RPM
Main EmptyOut DATA Save/Load Unload Auto-1 Auto-2 Auto-3					

Cut OD D1	Display the cutting wheel diameter
Cut width W1	Display the cutting wheel width
Cut remnant	Display the amount of the wheel that can still be used
Cut compensation	Display the wheel compensate amount
P to S distance	Display distance between wheel and feeder
Cut probe POS	Display the position of cut off wheel
Bar OD (D)	Display the cutting bar diameter
Bar length	Display the cutting bar length
Finish TOOL	Display how many pcs. have been cut
Finish Bar	Display how many bars have been finished
Working speed	Display present feed speed
Cut RPM	Display the speed of the cut off wheel

5.6 Auto Mode Page 3



Power off Control: Power on/off control.

Left clamp Down/Release: Choose left finger movement Down/Release.

Cut probe Disable/Enable: Open/close wheel detection function.

Load cushion Cylinder enable: Open/close load cushion cylinder movement.


Skip 1st Right press: Choose 1st cut right finger, do not press function

NO Push offcut: Choose to push offcut or not.

Offcut not remove: Choose the offcut remove function start or close.


Offcut remove R Press clamp: Offcut blow function open, the right finger clamp or not when this function is working.

5.7 Manual Mode Page 1




In this page, you can manually check all sensor functions and cylinder condition.

5.8 Manual Mode Page 2



5.9 Manual Mode Page 3



In this page, you can check the X and Y axis position.

5.10 Parameter Setting Page 1

<<Cut 1 Bar>>		Facing length(Lx)	0.150 inch
Bar OD (D)	0.167 inch	Offcut length(XX)	0.721 inch
Bar length (L)	3.996 inch	Cut length L1	1.500 inch
Cut OD (D1)	7.894 inch	PCS N1	2 (pcs)
Cut width (W1)	0.042 inch	Cut length L2	0.000 inch
Cut min OD	7.283 inch	PCS N2	0 (pcs)
Left Press Height	-0.202 0.395	Cut length L3	0.000 inch
Left Press UP		PCS N3	0 (pcs)
Main		Par-1 Cut Par	Par-2 Speed
		Par-3 Safe Par	Par-4 Probe/Time

Bar OD (D)	Input bar diameter
Bar length (L)	Input bar length
Cut OD (D1)	Input cutoff wheel diameter
Cut width (W1)	Input wheel width
Cut min. OD	Input minimum diameter with which the wheel can be used
Facing length (Lx)	Input facing length
Cutting length L1	Input 1 st cutting length
PCS N1	Input how many pcs. you need for L1
Cutting length L2	Input 2 nd cutting length
PCS N2	Insert how many pcs. you need for L2
Cutting length L3	Input 3 rd cutting length
PCS N3	Input how many pcs. you need for L3
Off cut length	Calculate automatically by program

Formula:

1. Calculate how many pieces you can cut off. Input LX and L1; the program will generate N1 and xx automatically.
2. Divide the bar average. Input the LX and N1; the program will generate L1 and xx automatically.
3. No remain material mode. LX=0; input the L1 and N1. The program will automatically let the material that remains to be the facing length.

5.11 Parameter Setting Page 2

Parameter - 2

Y Decelerate distance	0.079 inch	Decelerate speed	4.724 inch/M
1st Feed %	45.000 0.225 inch	1 st cut speed	3.000 inch/M
2st Feed %	40 0.200 inch	2 st cut speed	2.500 inch/M
3st Feed %	15 0.075 inch	3 st cut speed	3.000 inch/M
Over cut amount	0.079 inch	Over cut speed	4.724 inch/M
The total depth of cut	0.500 inch	Cutting off pause time	0.5 (sec)

Bar_D= 0.500
 Cut_D1= 7.894



Speed Data Set
 Speed List

Main
Par-1 Cut Par
Par-2 Speed
Par-3 Safe Par
Par-4 Probe/Time

Y Decelerate distance	Set up the saw and turn at slow speed until touch position distance	
1 st Feed amount	Feed amount 1 st (see picture)	
2 nd Feed amount	Feed amount 2 nd (see picture)	
3 rd Feed amount	Feed amount 3 rd (see picture)	
Over cut amount	Set up overcut distance	
Total depth of cut	Set up total depth of cut	
Decelerate speed	Set up saw downward speed in cushion distance	
1 st Cut speed	Set up 1 st feed speed	
2 nd Cut speed	Set up 2 nd feed speed	
3 rd Cut speed	Set up 3 rd feed speed	
Over cut speed	Set up over cut feed speed	
Cut off pause time	Set up pause time at finish position	
Cut D		Bar D

5.12 Parameter Setting Page 3

Parameter - 3					
X Feed fast speed	708.600	inch/M	Y Cut fast speed	165.340	inch/M
X First feed speed	100.000	inch/M	Y Cut safe speed	70.860	inch/M
X Feed slow speed	118.100	inch/M	Y Cut slow speed	23.620	inch/M
X Feed safe distance (X1)	1.575	inch	Y Cut push offcut safe height (SH)	0.205	inch
X Feed push offcut distance (X2)	0.079	inch	Y Cut load Safe height (SD)	0.205	inch

Main
Par-1
Cut Par
Par-2
Speed
Par-3
Safe Par
Par-4
Probe/Time

X feed fast speed	Feeder (X axis) fast move speed
X first feed speed	
X feed slow speed	Feeder (X axis) slow speed when push material
X feed safe distance (X1)	X1
X feed push offcut distance (X2)	X2
Y Cut fast speed	Saw (Y axis) fast move speed
Y cut safe speed	
Y cut slow speed	
Y cut push offcut safe height	Saw position avoid feeder crash when push the offcut
Y cut load safe distance SD	Saw position avoid feeder feed bar and crash

5.13 Parameter Setting Page 4

Parameter - 4						
Cut detect interval	5	count	Probe speed	23.620	inch/M	
Cut probe max error	0.079	inch	Loading wait time	1.0	(sec)	
Cut alert level	0.000	inch	R-Press delay time-1	0.0	(sec)	
Finish Segment Set	0	(pcs)	R-Press delay time-2	0.5	(sec)	
Finish Bar Set	0	(pcs)	L-Press delay time	0.0	(sec)	
Cut compensate pcs	0	(pcs)	Probe blow time	0.5	(sec)	
Cut abrasion compensation amount	0.000	inch	Offcut blow time	0.0	(sec)	
Cut probe compensate	0.000	inch	Left press width	3.937	inch	
Main	EmptyOut	DATA Save\Load	Par-1 Cut Par	Par-2 Speed	Par-3 Safe Par	Par-4 Probe Time

Cut detect interval	Set up to cut how many times wheel will do detection; check the OD once
Cut compensate pcs.	Set up to cut how many times the wheel will compensate to make sure it can cut through the bar
Cut abrasion compensation amount	Set up compensate amount
Cut probe max error	Set up the detect difference max. value
Cut alert level	Set up the offcut amount that machine will show alarm
Cut probe compensate	
Finish Tool set	Set up to cut number of pieces; will stop when finished
Finish bar set	Set up to cut number of bars; will stop when finished
Probe speed	Set up the wheel detect movement speed
Loading wait time	Set up the load box wait time; should be longer until the feeder push bar to go home
Right press delay time	Set up right finger move delay time
Left press delay time	Set up left finger move delay time
Probe blow time	Set up the wheel detection blow off time
Offcut blow time	Set up the offcut material blow off time

5.14 Position Setting Page 1

X	0.001	Y	0.000	Yh	-0.000	#4	0.193	unit inch
Y Cut push offcut safe height (SH)	0.197	Bar OD(D)	0.167					
Y Cut load Safe height (SD)	0.197	Bar length(L)	3.996					
Cut contact POS.	2.244	Left Press Height	-0.202	0.395				
1ST CUT POS.	2.319							
2ST CUT POS.	2.386							
3ST CUT POS.	2.411							
Over cut POS.	2.490							
Main	X 1	X 10	Cut POS Set-1	Cut probe Ste-2	Center dist. Set-3			

5.15 Position Setting Page 2

X	0.000	Y	-0.174	Yh	-0.179	#4	-0.105	
Cut probe POS	1.237	Safe door Open	Reset					
Cut probe start POS	0.787							
New Cut OD	7.894	Cut probe Blow OFF						
New cut probe POS	1.237							
Cut abrasion	0.000							
New Cut Probe								
Main	X 1	X 10	Cut POS Set-1	Cut probe Ste-2	Center dist. Set-3			

5.16 Position Setting Page 3

X	0.000	Y	-0.174	Yh	-0.179	#4	-0.105	unit inch
Now Cut OD(Dc)	7.894							
Test Bar OD(Db)	0.500							
Test Bar Length(Lb)	3.937							
Bar touch POS	1.678							
Feed HM to Cut HM	18.895	X Home						
Cut(Y) Center to V bottom	6.229	Y Home						
Main	X 1	X 10	Cut POS Set-1	Cut probe Ste-2	Center dist. Set-3			

5.17 System Parameter Page 1 (Password: 89823631)

System - 1					
X Axis HM Speed	3.937	inch/M	Left press width	3.937	inch
Y Axis HM Speed	0.787	inch/M	X Axis Acc time (TA)	100	(msec)
X Axis HM Offset	-0.709	inch	Y Axis Dec time (TA)	200	(msec)
Y Axis HM Offset	0.118	inch	Load box and Cut distance	1.969	inch
X Axis JOG Speed	3.937	inch/M	X Feed push offcut distance (X2)	0.079	inch
Y Axis JOG Speed	1.969	inch/M	Y Cut push offcut safe height (SH)	0.197	inch

中文 English 日本語

Main Sys-1 Sys-2 Sys-3 Sys-4

5.18 System Parameter Page 2

System - 2					
Y	-0.174	Yh	-0.179	ENC3	-56
Max feedback error limit(Y)	2.500	Cut Horizontal Set		407	
Y rotate Radius(Rb)	7.953				
Y rotate Radius(Rf)	12.815				
Encoder Count	25000				
Cut HM Angle($\theta 0$)	5.861				
Cut HM Height(H0)	1.309	Y-Yh	0.005	Max ΔY	0.016
Cut Now angle($\theta 1$)	-6.667				


Main X 1 X 10 Sys-1 Sys-2 Sys-3 Sys-4

5.19 System Parameter Page 3

System - 3				
Working total amount clear		Max Bar length	17.717	inch
L1 Finish Tool	0 (pcs)	Load cushion Cylinder limit	3.937	inch
L2 Finish Tool	0 (pcs)	Y-axis height limit press bar	0.197	inch
L3 Finish Tool	0 (pcs)	2V Extend Cylinder X-POS Limit	0.000	inch
Finish Tool	0 (pcs)			
Finish Bars	0 (pcs)			
Total Finish Tool	0 (pcs)			

Main Sys-1 Sys-2 Sys-3 Sys-4

5.20 System Parameter Page 4



5.21 Alarm Message

Alarm clear	System OK	Data	Time
1	System OK	Date	Time
2	System OK	Date	Time
3	System OK	Date	Time
4	System OK	Date	Time
5	System OK	Date	Time
6	System OK	Date	Time
7	System OK	Date	Time
8	System OK	Date	Time
9	System OK	Date	Time
10	System OK	Date	Time
11	System OK	Date	Time
12	System OK	Date	Time
13	System OK	Date	Time
14	System OK	Date	Time
15	System OK	Date	Time
16	System OK	Date	Time
17	System OK	Date	Time
18	System OK	Date	Time
19	System OK	Date	Time
20	System OK	Date	Time
Main	Prog SAVE OK > Power OFF and Power-ON again	Date	Exit

5.22 Alarm Troubleshooting

No.	Alarm Code	Solution
1	Emergency stop	Release EM button
2	Saw cover Open	Set cover to work position
3	X Axis Servo alarm	Check the alarm code at 400w amplifier and reference table A
4	X Axis follow error	Check if anything at X axis is loose. Close machine and restart; make X home and try again.
5	X Axis back HM alarm	Check if anything sticks. Check X axis home sensor.
6	X Axis +LIM/-LIM alarm	Check X Axis +/- sensor in Manual page.

7	Reserved	
8	Y Axis Servo alarm	Check alarm code from 100w amplifier and reference table A
9	Y Axis follow error	Check if anything at Y axis is loose. Close machine and restart; make Y home and try again.
10	Y Axis back HM alarm	Check if anything sticks. Check Y axis home sensor.
11	Y Axis +LIM/-LIM alarm	Check Y Axis +/- sensor in Manual page.
12	Reserved	
13	Cut motor alarm	Check the solenoid switch if it is tripped (over load) MS3
14	Coolant motor alarm	Check the solenoid switch if it is tripped (over load) MS4
15	Track oil insufficient	Check if there is lubrication oil in the tank
16	Air pressure insufficient	Check the air pressure connection
17	Load up alarm	Check load up sensor M900
18	Load down alarm	Check load down sensor M901
19	Load wait alarm	Check load standby sensor M902
20	Right press alarm	Check right finger sensor M904
21	Left press alarm	Check left finger sensor M903
22	Short material cylinder alarm	Check short material sensor M905
23	Load cushion cylinder alarm	Check load cushion cylinder sensor M906 and M907
24	Door lock alarm	Check safety door lock M908
25	Offcut discharge alarm	Check the offcut discharge sensor M909
26	Coolant flow check alarm	Check the flow check sensor M910
27	Coolant level alarm	Check the coolant level sensor M911
28	Sensor / Cut probe sensor alarm	Check probe sensor M320
29	Cut probe error	Re-detect the wheel diameter
30	X Axis +Limit	Check the X axis and Y axis limit sensor
31	X Axis -Limit	
32	Y Axis +Limit	
33	Y Axis -Limit	
34	Over cut position feedback limit	Re-detect
35		Check wheel detect sensor
36		Re-detect wheel edge
37	Cut position is too low, cannot feed	Check wheel position
38	Reserved	
39	Reserved	
40	Reserved	

Reference A:

YASAKAWA AC SERVO MOTOR ALARM TABLE
Reference B:




6. Maintenance

No.	Item	Work	Interval	Notes
1	Cutting V tray	Clean	Weekly	Clean and lubricate as needed.
2	Coolant Tank	Clean and discharge	Weekly	Take precipitation power outside
3	Coolant	Check	Daily	Check coolant quality with refractometer.
		Check	1 month	Use mobil Vactra #2 or equivalent.
4	Lubrication Device	Check	Daily	Check on the track oil surface; less than 1/3 surface height, add
5	Return Coolant Tank	Discharge	Daily	Discharge oil in return tank
6	General Clean	Clean	Weekly	
7	Y Axis Guideway	Check	Weekly	

6.1 Coolant Oil Specifications: Material Safety

Recommended Coolant Oil for CH-CM0206: Grindex 10

6.2 Grinding Wheel Diagram and Photograph



6.3 Tool Box List

1	12" Adjust. Wrench	11	MUI wrench – 12
2	– screw driver (big)	12	MUI wrench – 13
3	– screw driver (small)	13	MUI wrench – 14
4	+ screw driver (big)	14	MUI wrench – 17
5	+ screw driver (small)	15	MUI wrench – 19
6	Hex wrench	16	MUI wrench – 26
7	MUI wrench – 6	17	Door key
8	MUI wrench – 7	18	Electric cabinet key
9	MUI wrench – 8		
10	MUI wrench – 10		

6.4 Other Machine Parts

1	Coolant tank
2	Wire with pump
3	Tube ½"
4	Tube 50mm
5	Plastic Tank
6	4mm Lubrication Outlet Tube

- A. Operational manual
- B. Coolant Tank with pump



6.5 I/O Table

UTC-400V			
J7	+V		
	M01	Saw Motor	ACSSR
	M02	Coolant Motor	ACSSR
	M03	Servo Axis Drive Power	ACSSR
	M04	Coolant Solenoid Valve	ACSSR
	M05	Light	ACSSR
	M06	Conveying Belt	ACSSR
	M07	Power OFF control	ACSSR
	M08		ACSSR
	COM		
J5	+V		
	M11	CUT	Press button
	M12	EM	Press button
	M13	(ON/OFF) Saw	Switch
	M14	Bit-0	M14/M15 ON/ON OFF/ON ON/OFF OFF/OFF
	M15	Bit-1	
	M16	Jog Switch: X axis feed / Y axis saw	Switch
	M17	Jog: Right/Downward	Press button
	M18	Jog: Left/Upward	Press button
	COM		
J6	+V		
	M21	Load Button	Press button
	M22	Saw Cover Sensor	Sensor
	M23		Input
	M24		Input
	M25		Input
	M26		Input
	M27		Input
	M28		Input
	COM		
J8	+5V		
	DA1		
	DA2		
	-12V		
	+12V		
	AD1	Cutting speed adjust. VR	M105
	AD2		M205
	PWM1		
	PWM2		
	0V		

J9	+5V	+5V Power	LGT-201-100 (Sumtak)
	A	A Phase Output	
	A/		
	B	B Phase Output	
	B/		
	0V	0V	
D1	+LIM	X Axis (feeder) + Limit	M122
	-LIM	X Axis (feeder) – Limit	M121
	HMF	X Axis home	M120
	+V		
	COM		
D2	+LIM	Y Axis Saw downward Limit Sensor	M22
	-LIM	Y Axis Saw Upward + home Sensor	M221
	HMF	Saw Detect Sensor	M220
	+V		
	COM		

A0170			
IN1	+13V		
	M900	Load cylinder Up sensor	Sensor
	M901	Load cylinder Down sensor	Sensor
	M902	Load cylinder Standby sensor	Sensor
	M903	Right press cylinder Up sensor	Sensor
	M904	Left press cylinder Up sensor	Sensor
	M905	Short material cylinder sensor	Sensor
	M906	Load cushion cylinder Up sensor	Sensor

	M907	Load cushion cylinder Down sensor	Sensor
	+13VG		
IN2	+13V		
	M908	Safety door lock sensor	Sensor
	M909	Offcut remove cylinder sensor	Sensor
	M910	Coolant flow check sensor	Sensor
	M911	Coolant water level alarm sensor	Sensor
	M912		Input
	M913		Input
	M914		Input
	M915		Input
	+13VG		
IN3	+13V		
	M916		Input
	M917		Input
	M918		Input
	M919		Input
	M920		Input
	M921		Input
	M922		Input
	M923		Input
	+13VG		
IN4	+13V		
	M924	Saw motor alarm	Input
	M925	Coolant motor overload alarm	Input
	M926	Track oil insufficient	Input
	M927	Air pressure insufficient	Input
	M928		Input
	M929		Input
	M930		Input
	M931		Input
	+13VG		
OUT1	+13V		
	M932	Load cylinder Up	DCSSR
	M933	Load cylinder Down	DCSSR
	M934	Left cylinder Down	DCSSR
	M935	Left cylinder Up	DCSSR
	M936	Right clamping cylinder ON down: OFF UP	DCSSR
	M937	Short material cylinder	DCSSR
	M938	Load cushion cylinder	DCSSR
	M939	Offcut blow out	DCSSR
	+13VG		

OUT2	+13V		
	M940	Safety door lock	DCSSR
	M941	Wheel detect blow	DCSSR
	M942	Spindle blow	DCSSR
	M943		DCSSR
	M944		DCSSR
	M945	Red	DCSSR
	M946	Yellow	DCSSR
	M947	Green	DCSSR
	+13VG		
J7	GND		
	+5V		
	+13VG		
	+13V		

6. Rush Machinery Warranty

For one year from date of delivery of the CH-CM0206 Double Servo Auto-Cut CNC Carbide Rod Cut-Off Machine – Single Rod, provided that the machine is installed and operated in accordance with the instruction manual, Rush Machinery will repair or replace any mechanical or electrical part(s) for the machine, if defective in material or workmanship, at no charge. To obtain service under this warranty, contact Rush Machinery, and, at our option, the defective part(s) may have to be returned with shipping charge prepaid by the user. Rush Machinery will, without charge, repair or replace defective part(s). This warranty does not apply to the following: shipping damage, damage or problems caused by abuse, accident, alteration, negligence, or failure to follow operating instructions. In no event will Rush Machinery, Inc. be liable for incidental or consequential damages.

Warning: the use of coolant oil or mixed coolants without proper fire suppression and mist collection is flammable and not recommended. The use of unapproved liquids may void the warranty.

For any maintenance, service, or parts needs, please contact the service department at:

Rush Machinery, Inc.
4761 Route 364
Rushville, NY 14544 USA

Tel: 800-929-3070 (Toll Free - USA & Canada)
or +1 585-554-3070
Fax: 585-554-4077

Email: mail@rushmachinery.com
Website: www.rushmachinery.com

Appendix A: Recommended Spare Parts List

Part #	Quantity	Description
CHL02001	2	One Way Flow Control Valve with Fittings
CHL03005	1	Loading Tray Material Proximity Sensor
CHL03044	1	Fiber Optic Line for Banner Sensor
CHL04051	1	Sawing Belt (Model CH-CM0206)
CHL02034	2	Clamping Cylinder (Model CH-CM0206)

Appendix B: Optional Accessories

100L Filtration System



Dimensions: 23.75" W x 33.128" L x 43.5" H (604mm x 841.5mm x 1105mm)

Flow capacity: 0–17 gpm at 58–26 (0–65 lpm at 4–1.8 bar)

Tank capacity: 26.4 gallons (100 Liters)

Pump HP: $\frac{3}{4}$ HP (0.5 KW)

40 μ Filter roll: 19.25" W x 164' L (49cm x 50m)

5 μ Filter bag: 4" diameter x 13.75" L (10cm x 35cm)

Supply Hose: 6.5' L (2m)

Fire Suppression System



Recommended when oil coolant is used

Automatic Thermal Sensor Detection

Manual Emergency Override

Electrically connected to Emergency Stop circuit

3M Novec 1230 Fire Protection Fluid

Manufacturer warranty applies

Mist Collector



Activated by Auto-Cut electronics

500 cfm

97.8% efficient

3-stage filtration

Water or oil collection

Manufacturer warranty applies

Mounting Options:

*Pedestal Stand with adjustable height (min. 65.5" to bottom of unit, max of 120" for top of unit) (P/N

*Ceiling Mount

*Wall Mount